

Stereo Instructions (Please turn off when not in use)

Only the Orange buttons (and labeled buttons) are active – make sure that the thumb selector on the right hand side is set to “**Amp**”

There are 5 speakers inside (front left and right, center, back left and right) plus a sub-woofer and 2 speakers outside. The volume can't be set differently for outside and inside (as of right now).

The “A” speakers are inside, “B” speakers are outside. If you only want the outside speakers on, the sub-woofer inside will still be on. You can turn it down from the knob on the sub-woofer, or using the “Level” menu (until you see sub-woofer displayed, then pressing left or right buttons to decrease or increase the volume) or by turning it off by the power bar (up to the left of the amp).

The **Power** Button turns the Amplifier On and the **Standby** button turns it Off.

To listen to the Radio:

Press the **Tuner** button. To change stations, change the thumb selector on the right side of the remote from **Amp** to **Source**. Now you can switch from the up to 40 preset stations (5 groups of 8 in each group, A to E). Press the A-E/CAT left and right buttons to change the group and PRESET/CH up and down buttons to move through the 8 channels in each group. Set the thumb selector back to AMP when done.

To listen to a CD:

The CD player is a combo CD and DVD 5 disc player on the shelf behind the bar. Load a CD into the tray and press the corresponding number on the front of the player. There is a remote attached to the player for more advanced features. To remove a disc, select a different tray number than the one it is in and then open the drawer. Do not move the tray manually! On the remote, press **DVD** (not CD)

To listen to a laptop:

There is a cable by the VCR and CD/DVD player on the shelf behind the bar. You can plug this into your laptop. To hear it, press the **MD/TAPE** button on the remote.

To use the microphone:

The wireless Mic is kept locked in the office. It has a On/Standby/Off switch on the bottom and should be set to Off when not in use. Hold it about 1 foot away from your mouth (everyone's voice is a little different), make sure you don't talk too loud or too close or it will distort the sound and may hurt the speakers. Keep the volume low on the amplifier and hit the **CD** button on the remote. Slowly increase the volume.

There are two devices beside the amp that control the wireless input. The settings control the sensitivity of the Mic and how loud it inputs to the amp. You shouldn't have to adjust these.

For the fullest sound:

The “Program” mode should be set to “**7 Channel Stereo**” to hear all the inside speakers. Make sure the thumb selector is set to **Amp**

Hit the button marked **Stereo (1)** on the remote and then hit the left or right buttons (beside the enter button) to switch between **2-Channel** and **7-Channel** speakers