

## Controlling Projector/Satellite/DVD/VCR and Stereo

The Remote is attached to the wall to right of the drop-down screen (to the right of the dart boards)

**\*\*\*All Devices should be turned off when not in use\*\*\***

The Satellite receiver, Stereo, DVD and VCR can be turned off by the remote. The projector has a 2 stage shutdown process (to protect the bulb). You first turn it off by the remote and then after a cool-down period of a few minutes, you manually turn it off.

### To Start:

**Turn the projector on.** Remove the dust cap over the lens. The On/Off switch is just above the power cord. You will have to get the small ladder out of the kitchen storage area to be able to reach it. The switch is located at the back of the projector at the top left. Once that switch is turned on, a green Power light and amber Ready light will glow. (The amber light will flash until the projector is ready, when it will turn solid).

The projector is now ready to accept video from the Satellite, DVD, VCR or a laptop. Since each of these sources come in various sizes, you can adjust the zoom on the projector (the roller just under the lens) or slide the whole projector on the wooden mount. The focus is the ring around the lens. For an HD Satellite signal, push the mount back so that it fills the whole screen. Other signals are smaller and you will have to push the projector in a bit (and adjust the zoom)

The audio signals from these devices go to the Stereo amplifier. The remote near the projector can control all 5 devices. All instructions below are for this remote.

**Turn the Stereo on.** On the remote, press the **Device** button. All 5 devices are listed there (3 per screen). You may have to push **Next** to see the device you want to control. Look for **Stereo** and press either the grey button to the left or to the right of it. Now any buttons you press will direct the Stereo to do something. (The stereo is over the top of the bar, so the remote must be pointed that way). The **Volume** and **Mute** buttons work and you have other choices in the screen on the remote. You can choose audio sources between the *Satellite*, *DVD*, *VCR* and a *computer* input, as well as turning the Stereo On and Off (after pushing the **Next** button).

**\*\*\*For best sound, the program on the Stereo should be set to 7ch Stereo – see the Stereo guide for how to change this.**

### Watch Satellite TV:

(Aim at the satellite box above the dart boards)

Remote: Device = Satellite, Press the grey button beside **On/Off** on the screen. The satellite receiver unit will light up with orange lights.

(Now aim at the projector)

Remote: Device = Projector, Press the grey button beside **On/Off** on the screen

The amber Ready light will go out on the projector. You will see a warm-up image on the screen. You may have to press **Source** on the remote's screen to scroll through the available video sources. The Satellite will be **Component Video 1080i**.

You can use the Guide and Channel select buttons to change channels. The HD channels are below #300, but not all shows are in HD. The channel name will end in HD (i.e.: #288, PBSSEHD), but you also have to look for a black icon in the program listing showing **HDTV**.

Now to get some sound! (Aim at the Stereo)

Remote: Device = Stereo, Press the grey button beside **Satellite**.

You can change the volume or mute while in this mode

\*\*\*Remember: to change the channels, device must be set to Satellite and to change sound, Device must be set to Stereo (and the remote pointing at the correct device)

### Watch a DVD:

Turn on the DVD player (on a shelf behind the bar, the bottom unit). This unit can play DVD's or CD's, up to 5 at a time. Insert your DVD and press the number of the slot you put it into on the front of the unit. There is a remote specifically for the DVD player attached to it. It allows you to access all the features of the player.

The video signal is controlled by the Stereo, so: (aim at the Stereo)

Remote: Device = Stereo, Press the grey button beside **DVD**.

You can change the volume or mute while in this mode

(Now aim at the projector)

Remote: Device = Projector, Press the grey button beside **On/Off** on the screen

The amber Ready light will go out on the projector. You will see a warm-up image on the screen. You may have to press **Source** on the remote's screen to scroll through the available video sources. The DVD will be **S-Video**.

(Now aim at the DVD player)

Remote: Device = DVD. You can turn it On/Off, switch discs, Pause, Play, Fast Forward, etc.

To remove your disc from the player, select a different disc on the front panel, then Open the disc drawer. Don't manually move the disc tray around!!

### **Watch a VCR:**

Turn on the VCR player (on a shelf behind the bar, the top unit).

The video signal is controlled by the Stereo, so: (aim at the Stereo)

Remote: Device = Stereo, Press the grey button beside **VCR**.

You can change the volume or mute while in this mode

(Now aim at the projector)

Remote: Device = Projector, Press the grey button beside **On/Off** on the screen

The amber Ready light will go out on the projector. You will see a warm-up image on the screen. You may have to press **Source** on the remote's screen to scroll through the available video sources. The VCR will be **S-Video (NTSC)**.

(Now aim at the VCR player)

Remote: Device = VCR. You can turn it On/Off, Pause, Play, Fast Forward, etc. (the screen might go blank – you will have to set the projector back to Source=VCR)

### **Watch from a computer:**

The video signal is controlled by a cable dropped down from the projector that plugs into your computer.

(Now aim at the projector)

Remote: Device = Projector, Press the grey button beside **On/Off** on the screen

The amber Ready light will go out on the projector. You will see a warm-up image on the screen. You may have to press **Source** on the remote's screen to scroll through the available video sources. The Computer will be **DVI** or **Analog** (depending on your unit).

Sound: There is another dropdown cable for audio from your computer coming from the projector going to the Stereo.

(Aim at the Stereo)

Remote: Device = Stereo, Press the grey button beside **Laptop**.

You can change the volume or mute while in this mode

### **When you are done:**

Turn off all devices: DVD, VCR (manually), Satellite and Stereo with the remote.

The projector takes 2 steps:

On the remote, aim at the projector, press Device = Projector, hit the grey button beside ON/Off **twice**. This will shut off the lamp but it needs to cool down for about 2 minutes. The amber Ready light will flash during this time. Once it goes solid, you can manually turn off the projector and place the dust cap over the lens. (Be careful! The unit can get quite hot to the touch).